

Multiple metering



Contents

| Description | Page |
|--------------------------------|------|
| Meter packs | 2 |
| Main devices | 3 |
| Residential meter stacks | 6 |
| Commercial meter stacks | 7 |
| Miscellaneous parts | 8 |



Powering Business Worldwide

Meter packs




Figure 1. Meter Pack

Table 1. Meter Packs

Catalog Numbers

| Meter Pack | Utility Pull Section Cover | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbars |
|---------------------|----------------------------|---------------|-----------------------|----------------------|-------------|--------------------------|-----------------------------|------------------|
| 1MP2122R | MP2122UCVR | MPCCVR01 | 1MMMS | 1MMBC1 | 1MMCP1 | MP122NWLK | MP122NWL | MM1223VBUS |
| 1MP3124R | MP1234UCVR | MPCCVR04 | 1MMMS | 1MMBC1 | 1MMCP1 | MP1234NWLK | MP1234NWL | MM1223VBUS |
| 1MP4124R | MP1234UCVR | MPCCVR05 | 1MMMS | 1MMBC1 | 1MMCP1 | MP1234NWLK | MP1234NWL | MM124VBUS |
| 1MP5126R | MP1256UCVR | MPCCVR02 ① | 1MMMS | 1MMBC1 | 1MMCP1 ② | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP6126R | MP1256UCVR | MPCCVR03 ① | 1MMMS | 1MMBC1 | 1MMCP1 ② | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP2204R | MP202UCVR | MPCCVR06 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM202VBUS |
| 1MP3206R | MP2034UCVR | MPCCVR09 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM2023VBUS |
| 1MP4206R | MP2034UCVR | MPCCVR10 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM204VBUS |
| 1MP5206R | MP2056UCVR | MPCCVR07 ③ | 1MMMS | 1MMBC2 | 1MMCP2 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP6206R | MP2056UCVR | MPCCVR08 ③ | 1MMMS | 1MMBC2 | 1MMCP2 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP2122RRL ④ | MP2122LUCVR | MPCCVR01 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP122NWLK | MP122NWL | MM1223VBUS |
| 1MP3124RRL ④ | MP1234UCVR | MPCCVR04 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1234NWLK | MP1234NWL | MM1223VBUS |
| 1MP4124RRL ④ | MP1234UCVR | MPCCVR05 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 | MP1234NWLK | MP1234NWL | MM124VBUS |
| 1MP5126RRL ④ | MP1256UCVR | MPCCVR02 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP6126RRL ④ | MP1256UCVR | MPCCVR03 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP2204RRL ④ | MP202UCVR | MPCCVR06 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM202VBUS |
| 1MP3206RRL ④ | MP2034UCVR | MPCCVR09 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM2023VBUS |
| 1MP4206RRL ④ | MP2034UCVR | MPCCVR10 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM204VBUS |
| 1MP5206RRL ④ | MP2056UCVR | MPCCVR07 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP6206RRL ④ | MP2056UCVR | MPCCVR08 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2056NWLK | MP2056NWL | MM2023VBUS |

① For center wireway cover, order MPCENCVR1.

② For top position, use meter socket cover 1MMCP1T.

③ For center wireway cover, order MPCENCVR2.

④ For catalog numbers with a "B" suffix (ringless with horn bypass), all replacement parts are the same with the exception of the meter socket assembly. Refer to Footnote 5 for correct catalog number.

⑤ For ringless style meter packs with horn bypass, order 1MMMSB.

⑥ For top position, use meter socket cover 1MMRC125T.

Main devices




Figure 2. Main Device Panel

Table 2. End Caps

| Description | Catalog Numbers |
|---------------------|-----------------|
| Right side (bumped) | 47-28172-2A |
| Left side (flat) | 47-24139A |

Table 3. Terminal Box

| Catalog Numbers | | | | |
|-----------------|-------------|-----------|--------------------------|-----------------------------|
| Terminal Box | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
| 1MTB800R | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MTB1200R | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MTB400R | MTBFCVR1 | MMDH4 | MTBEW1 | MTBEWVK01 |
| 3MTB600R | MTBFCVR1 | MMDH4 | MTBEW1 | MTBEWVK01 |
| 3MTB800R | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MBT1200R | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |

Effective January 2012

Main devices (continued)**Table 4. Main Circuit Breaker****Catalog Numbers**

| Circuit Breaker | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|------------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 1MCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1400RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1400RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1600RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1600RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB2000RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB2000RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1400RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1400RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1600RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1600RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB2000RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB2000RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |

Main devices (continued)**Table 5. Main Fusible Switch****Catalog Numbers**

| Fusible Switch | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|-----------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 1MFS400RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS400RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS600RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS600RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS800RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS800RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS1200RB | MFSFCVR2 | MMDH2 | MMEW2 | MMEWVK02 |
| 3MFS400RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS400RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS600RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS600RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS800RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS800RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS1200RB | MFSFCVR2 | MMDH2 | MMEW2 | MMEWVK02 |

Table 6. Main Bolted Pressure Contact Switch**Catalog Numbers**

| Bolted Pressure Contact Switch | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|---------------------------------------|--|------------------|---------------------------------|------------------------------------|
| 1BPS1200RB | No replacement parts available at this time. | | | |
| 1BPS1200RT | | | | |
| 3BPS1200RB | | | | |
| 3BPS1200RT | | | | |
| 3BPS1600RB | | | | |
| 3BPS1600RT | | | | |
| 3BPS2000RB | | | | |
| 3BPS2000RT | | | | |

Table 7. Main Fusible Switch with Pullbox**Catalog Numbers**

| Fusible Switch with Pullbox | Front Cover | Pullbox Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|------------------------------------|--------------------|----------------------|------------------|---------------------------------|------------------------------------|
| 1MFS400RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS600RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS800RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS1200RUG | MFPFCVR2 | MFPBCVR2 | MMDH2 | MMEW2 | MMEWVK02 |
| 3MFS400RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS600RUG | MFPFCVR3 | MFPBCVR3 | MMDH5 | MMEW4 | MMEWVK04 |
| 3MFS800RUG | MFPFCVR3 | MFPBCVR3 | MMDH5 | MMEW4 | MMEWVK04 |
| 3MFS1200RUG | MFPFCVR2 | MFPBCVR2 | MMDH2 | MMEW2 | MMEWVK02 |

Table 8. Pullbox**Catalog Numbers**

| Pullbox | Front Cover/Pullbox Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|----------------|----------------------------------|------------------|---------------------------------|------------------------------------|
| 1UGPB400R | PBFCVR1 | PBDH1 | PBEW1 | PBEWVK01 |
| 1UGPB800R | PBFCVR2 | PBDH2 | PBEW2 | PBEWVK02 |
| 1UGPB1200R | PBFCVR3 | PBDH3 | PBEW3 | PBEWVK03 |
| 3UGPB400R | PBFCVR1 | PBDH1 | PBEW1 | PBEWVK01 |
| 3UGPB800R | PBFCVR2 | PBDH2 | PBEW2 | PBEWVK02 |
| 3UGPB1200R | PBFCVR3 | PBDH3 | PBEW3 | PBEWVK03 |

Residential meter stacks




Figure 3. Residential Meter Stack

Table 9. Residential Meter Stacks

Catalog Numbers

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbar |
|-------------|---------------|-----------------------|----------------------|-------------|-----------|--------------------------|-----------------------------|-----------------|
| 3MM212 | MMCCVR2123 | — | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM212R | MMCCVR2123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM312 | MMCCVR3121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM312R | MMCCVR3121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM312 | MMCCVR3123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM312R | MMCCVR3123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM412 | MMCCVR4121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 1MM412R | MMCCVR4121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 3MM412 | MMCCVR4123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 3MM412R | MMCCVR4123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 1MM512 | MMCCVR5121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 1MM512R | MMCCVR5121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 3MM512 | MMCCVR5123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 3MM512R | MMCCVR5123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 1MM612 | MMCCVR6121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 1MM612R | MMCCVR6121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM612 | MMCCVR6123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM612R | MMCCVR6123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM220 | MMCCVR2203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM220R | MMCCVR2203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM320 | MMCCVR3201 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM320R | MMCCVR3201R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM320 | MMCCVR3203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM320R | MMCCVR3203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM420 | MMCCVR4201 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 1MM420R | MMCCVR4201R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |

① NEMA® 1 meter stacks do not come with breaker covers.

Residential meter stacks (continued)**Table 9. Residential Meter Stacks (Continued)****Catalog Numbers**

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbar |
|--------------------|---------------|-----------------------|----------------------|-------------|-----------|--------------------------|-----------------------------|-----------------|
| 3MM420 | MMCCVR4203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 3MM420R | MMCCVR4203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 3MM212RRL ② | MMCCVR2123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 1MM312RRL ② | MMCCVR3121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 3MM312RRL ② | MMCCVR3123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 1MM412RRL ② | MMCCVR3121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM124VBUS |
| 3MM412RRL ② | MMCCVR4123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM124VBUS |
| 1MM512RRL ② | MMCCVR5121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM125VBUS |
| 3MM512RRL ② | MMCCVR5123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM125VBUS |
| 1MM612RRL ② | MMCCVR6121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM126VBUS |
| 3MM612RRL ② | MMCCVR6123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM126VBUS |
| 3MM220RRL ② | MMCCVR2203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 1MM320RRL ② | MMCCVR3201R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 3MM320RRL ② | MMCCVR3203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 1MM420RRL ② | MMCCVR4201R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM204VBUS |
| 3MM420RRL ② | MMCCVR4203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM204VBUS |

① NEMA® 1 meter stacks do not come with breaker covers.

② For catalog numbers with a "B" suffix (ringless with horn bypass), all replacement parts are the same with the exception of the meter socket assembly. Refer to Footnote 2 for correct catalog number.

③ For ringless style meter stacks with horn bypass, order 1MMMSB meter socket assembly.

④ For top position, use meter socket cover 1MMRC125T.

Commercial meter stacks**Table 10. Commercial Meter Stacks (Lever Bypass)****Catalog Numbers**

| Meter Stack | Wireway Cover | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|-------------------|---------------|---------------|-----------------------|----------------------|-------------|-------------|-----------|--------------------------|-----------------------------|
| 35MM120R12 | MSLWCVR1 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM220R12 | MSLWCVR2 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM320R12 | MSLWCVR3 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM420R12 | MSLWCVR4 ① | MSLWCVR13 ② | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH2 | — | MSLEW2 |
| 37MM140R12 | MSLWCVR9 ① | MSLWCVR14 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM120R12 | MSLWCVR5 ① | MSLWCVR15 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM220R12 | MSLWCVR6 ① | MSLWCVR16 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM320R12 | MSLWCVR7 ① | MSLWCVR17 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM420R12 | MSLWCVR8 ① | MSLWCVR18 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH2 | — | MSLEW2 |

① Used for product built October 2002 and prior.

② Used for product built after October 2002.

Commercial meter stacks (continued)**Table 11. Commercial Meter Stack (Test Bypass)****Catalog Numbers**

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|--------------------|----------------------|------------------------------|-----------------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 35SS120RAB | MSTWCVR1 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS120RAC | MSTWCVR2 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS120RBC | MSTWCVR3 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS220RAB | MSTWCVR4 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS220RAC | MSTWCVR5 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS220RBC | MSTWCVR6 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RAB | MSTWCVR7 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RAC | MSTWCVR8 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RBC | MSTWCVR9 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 37SS120R | MSTWCVR10 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 37SS220R | MSTWCVR11 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 37SS320R | MSTWCVR12 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |

Miscellaneous parts**Table 12. Miscellaneous Parts**

| Description | Part Number |
|--|--------------------|
| Phase balancing kit, single-phase commercial metering | 99-4177-3 |
| A and C phase balancing kit (3MM) | 99-4184 |
| Breaker mounting kit, commercial metering (one three-pole breaker per kit) | 99-4176-2 |
| Breaker mounting kit, 1MM/1MP, 200A, (one two-pole breaker per kit) | 99-4176 |
| Mounting kit, meter center | 99-4172 |
| Mounting kit, meter pack | 99-4173 |
| Bonding strap kit, all meter packs (except CECHA three and four socket) | 99-4174 |
| Bonding strap kit, CHECA three and four socket meter packs | 99-2379 |
| Sealing screw kit, ringless devices (six screws) | 99-4175 |
| Sealing screw kit, three and four meter sockets, ringless devices (four screws) | 99-2589 |
| Padlock bracket | 99-2512-5 |
| Mounting bracket kit—All breaker and fusible mains | 99-4183 |
| Mounting bracket kit—400A and 600A 3MTB | 99-4183-3 |
| Exterior breaker cover | 49-6070 |

Eaton Corporation
Electrical Sector
1111 Superior Ave.
Cleveland, OH 44114
United States
Eaton.com

© 2012 Eaton Corporation
All Rights Reserved
Printed in USA
Publication No. RP00501001E / Z11822
January 2012

Eaton is a registered trademark
of Eaton Corporation.

All other trademarks are property
of their respective owners.

Multiple metering



Contents

| Description | Page |
|--------------------------------|------|
| Meter packs | 2 |
| Main devices | 3 |
| Residential meter stacks | 6 |
| Commercial meter stacks | 7 |
| Miscellaneous parts | 8 |



Powering Business Worldwide

Meter packs




Figure 1. Meter Pack

Table 1. Meter Packs

Catalog Numbers

| Meter Pack | Utility Pull Section Cover | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbars |
|---------------------|----------------------------|---------------|-----------------------|----------------------|-------------|--------------------------|-----------------------------|------------------|
| 1MP2122R | MP2122UCVR | MPCCVR01 | 1MMMS | 1MMBC1 | 1MMCP1 | MP122NWLK | MP122NWL | MM1223VBUS |
| 1MP3124R | MP1234UCVR | MPCCVR04 | 1MMMS | 1MMBC1 | 1MMCP1 | MP1234NWLK | MP1234NWL | MM1223VBUS |
| 1MP4124R | MP1234UCVR | MPCCVR05 | 1MMMS | 1MMBC1 | 1MMCP1 | MP1234NWLK | MP1234NWL | MM124VBUS |
| 1MP5126R | MP1256UCVR | MPCCVR02 ① | 1MMMS | 1MMBC1 | 1MMCP1 ② | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP6126R | MP1256UCVR | MPCCVR03 ① | 1MMMS | 1MMBC1 | 1MMCP1 ② | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP2204R | MP202UCVR | MPCCVR06 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM202VBUS |
| 1MP3206R | MP2034UCVR | MPCCVR09 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM2023VBUS |
| 1MP4206R | MP2034UCVR | MPCCVR10 | 1MMMS | 1MMBC2 | 1MMCP2 | MP2024NWLK | MP2024NWL | MM204VBUS |
| 1MP5206R | MP2056UCVR | MPCCVR07 ③ | 1MMMS | 1MMBC2 | 1MMCP2 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP6206R | MP2056UCVR | MPCCVR08 ③ | 1MMMS | 1MMBC2 | 1MMCP2 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP2122RRL ④ | MP2122LUCVR | MPCCVR01 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP122NWLK | MP122NWL | MM1223VBUS |
| 1MP3124RRL ④ | MP1234UCVR | MPCCVR04 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1234NWLK | MP1234NWL | MM1223VBUS |
| 1MP4124RRL ④ | MP1234UCVR | MPCCVR05 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 | MP1234NWLK | MP1234NWL | MM124VBUS |
| 1MP5126RRL ④ | MP1256UCVR | MPCCVR02 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP6126RRL ④ | MP1256UCVR | MPCCVR03 | 1MMMS ⑤ | 1MMBC1 | 1MMRC125 ⑥ | MP1256NWLK | MP1256NWL | MM1223VBUS |
| 1MP2204RRL ④ | MP202UCVR | MPCCVR06 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM202VBUS |
| 1MP3206RRL ④ | MP2034UCVR | MPCCVR09 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM2023VBUS |
| 1MP4206RRL ④ | MP2034UCVR | MPCCVR10 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2024NWLK | MP2024NWL | MM204VBUS |
| 1MP5206RRL ④ | MP2056UCVR | MPCCVR07 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2056NWLK | MP2056NWL | MM2023VBUS |
| 1MP6206RRL ④ | MP2056UCVR | MPCCVR08 | 1MMMS ⑤ | 1MMBC2 | 1MMRC200 | MP2056NWLK | MP2056NWL | MM2023VBUS |

① For center wireway cover, order MPCENCVR1.

② For top position, use meter socket cover 1MMCP1T.

③ For center wireway cover, order MPCENCVR2.

④ For catalog numbers with a "B" suffix (ringless with horn bypass), all replacement parts are the same with the exception of the meter socket assembly. Refer to Footnote 5 for correct catalog number.

⑤ For ringless style meter packs with horn bypass, order 1MMMSB.

⑥ For top position, use meter socket cover 1MMRC125T.

Main devices




Figure 2. Main Device Panel

Table 2. End Caps

| Description | Catalog Numbers |
|---------------------|-----------------|
| Right side (bumped) | 47-28172-2A |
| Left side (flat) | 47-24139A |

Table 3. Terminal Box

| Catalog Numbers | | | | |
|-----------------|-------------|-----------|--------------------------|-----------------------------|
| Terminal Box | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
| 1MTB800R | MMFCVR1 | MMDH1 | MMEW1 | MMEWNK01 |
| 1MTB1200R | MMFCVR1 | MMDH1 | MMEW1 | MMEWNK01 |
| 3MTB400R | MTBFCVR1 | MMDH4 | MTBEW1 | MTBEWNK01 |
| 3MTB600R | MTBFCVR1 | MMDH4 | MTBEW1 | MTBEWNK01 |
| 3MTB800R | MMFCVR1 | MMDH1 | MMEW1 | MMEWNK01 |
| 3MBT1200R | MMFCVR1 | MMDH1 | MMEW1 | MMEWNK01 |

Effective January 2012

Main devices (continued)**Table 4. Main Circuit Breaker****Catalog Numbers**

| Circuit Breaker | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|------------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 1MCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MHCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MCB1400RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1400RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1600RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB1600RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB2000RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 1MCB2000RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB250R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB300R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB350R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB400R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB500R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB600R | MCBFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB700R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB800R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB900R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB1000R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MHCB1200R | MCBFCVR2 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MCB1400RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1400RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1600RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB1600RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB2000RB | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |
| 3MCB2000RT | MCBFCVR3 | MCBDH1 | — | MMEWVK03 |

Main devices (continued)**Table 5. Main Fusible Switch****Catalog Numbers**

| Fusible Switch | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|-----------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 1MFS400RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS400RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS600RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS600RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS800RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS800RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 1MFS1200RB | MFSFCVR2 | MMDH2 | MMEW2 | MMEWVK02 |
| 3MFS400RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS400RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS600RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS600RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS800RB | MMFCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS800RT | MFSFCVR1 | MMDH1 | — | MMEWVK01 |
| 3MFS1200RB | MFSFCVR2 | MMDH2 | MMEW2 | MMEWVK02 |

Table 6. Main Bolted Pressure Contact Switch**Catalog Numbers**

| Bolted Pressure Contact Switch | Front Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|---------------------------------------|--|------------------|---------------------------------|------------------------------------|
| 1BPS1200RB | No replacement parts available at this time. | | | |
| 1BPS1200RT | | | | |
| 3BPS1200RB | | | | |
| 3BPS1200RT | | | | |
| 3BPS1600RB | | | | |
| 3BPS1600RT | | | | |
| 3BPS2000RB | | | | |
| 3BPS2000RT | | | | |

Table 7. Main Fusible Switch with Pullbox**Catalog Numbers**

| Fusible Switch with Pullbox | Front Cover | Pullbox Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|------------------------------------|--------------------|----------------------|------------------|---------------------------------|------------------------------------|
| 1MFS400RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS600RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS800RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 1MFS1200RUG | MFPFCVR2 | MFPBCVR2 | MMDH2 | MMEW2 | MMEWVK02 |
| 3MFS400RUG | MFPFCVR1 | MFPBCVR1 | MMDH1 | MMEW1 | MMEWVK01 |
| 3MFS600RUG | MFPFCVR3 | MFPBCVR3 | MMDH5 | MMEW4 | MMEWVK04 |
| 3MFS800RUG | MFPFCVR3 | MFPBCVR3 | MMDH5 | MMEW4 | MMEWVK04 |
| 3MFS1200RUG | MFPFCVR2 | MFPBCVR2 | MMDH2 | MMEW2 | MMEWVK02 |

Table 8. Pullbox**Catalog Numbers**

| Pullbox | Front Cover/Pullbox Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|----------------|----------------------------------|------------------|---------------------------------|------------------------------------|
| 1UGPB400R | PBFCVR1 | PBDH1 | PBEW1 | PBEWVK01 |
| 1UGPB800R | PBFCVR2 | PBDH2 | PBEW2 | PBEWVK02 |
| 1UGPB1200R | PBFCVR3 | PBDH3 | PBEW3 | PBEWVK03 |
| 3UGPB400R | PBFCVR1 | PBDH1 | PBEW1 | PBEWVK01 |
| 3UGPB800R | PBFCVR2 | PBDH2 | PBEW2 | PBEWVK02 |
| 3UGPB1200R | PBFCVR3 | PBDH3 | PBEW3 | PBEWVK03 |

Residential meter stacks




Figure 3. Residential Meter Stack

Table 9. Residential Meter Stacks

Catalog Numbers

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbar |
|-------------|---------------|-----------------------|----------------------|-------------|-----------|--------------------------|-----------------------------|-----------------|
| 3MM212 | MMCCVR2123 | — | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM212R | MMCCVR2123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM312 | MMCCVR3121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM312R | MMCCVR3121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM312 | MMCCVR3123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 3MM312R | MMCCVR3123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM1223VBUS |
| 1MM412 | MMCCVR4121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 1MM412R | MMCCVR4121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 3MM412 | MMCCVR4123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 3MM412R | MMCCVR4123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM124VBUS |
| 1MM512 | MMCCVR5121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 1MM512R | MMCCVR5121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 3MM512 | MMCCVR5123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 3MM512R | MMCCVR5123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM125VBUS |
| 1MM612 | MMCCVR6121 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 1MM612R | MMCCVR6121R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM612 | MMCCVR6123 | 1MMMS | ① | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM612R | MMCCVR6123R | 1MMMS | 1MMBC1 | 1MMCP1 | MMDH3 | MM12N1WLK | MM12N1WL | MM126VBUS |
| 3MM220 | MMCCVR2203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM220R | MMCCVR2203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM320 | MMCCVR3201 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM320R | MMCCVR3201R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM320 | MMCCVR3203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 3MM320R | MMCCVR3203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM2023VBUS |
| 1MM420 | MMCCVR4201 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 1MM420R | MMCCVR4201R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |

① NEMA® 1 meter stacks do not come with breaker covers.

Residential meter stacks (continued)**Table 9. Residential Meter Stacks (Continued)****Catalog Numbers**

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) | Vertical Busbar |
|--------------------|---------------|-----------------------|----------------------|-------------|-----------|--------------------------|-----------------------------|-----------------|
| 3MM420 | MMCCVR4203 | 1MMMS | ① | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 3MM420R | MMCCVR4203R | 1MMMS | 1MMBC2 | 1MMCP2 | MMDH4 | MM20N1WLK | MM20N1WL | MM204VBUS |
| 3MM212RRL ② | MMCCVR2123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 1MM312RRL ② | MMCCVR3121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 3MM312RRL ② | MMCCVR3123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM1223VBUS |
| 1MM412RRL ② | MMCCVR3121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM124VBUS |
| 3MM412RRL ② | MMCCVR4123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM124VBUS |
| 1MM512RRL ② | MMCCVR5121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM125VBUS |
| 3MM512RRL ② | MMCCVR5123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM125VBUS |
| 1MM612RRL ② | MMCCVR6121R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM126VBUS |
| 3MM612RRL ② | MMCCVR6123R | 1MMMS ③ | 1MMBC1 | 1MMRC125 ④ | MMDH3 | MM12NWLK | MM12NWL | MM126VBUS |
| 3MM220RRL ② | MMCCVR2203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 1MM320RRL ② | MMCCVR3201R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 3MM320RRL ② | MMCCVR3203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM2023VBUS |
| 1MM420RRL ② | MMCCVR4201R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM204VBUS |
| 3MM420RRL ② | MMCCVR4203R | 1MMMS ③ | 1MMBC2 | 1MMRC200 | MMDH4 | MM20NWLK | MM20NWL | MM204VBUS |

① NEMA® 1 meter stacks do not come with breaker covers.

② For catalog numbers with a "B" suffix (ringless with horn bypass), all replacement parts are the same with the exception of the meter socket assembly. Refer to Footnote 2 for correct catalog number.

③ For ringless style meter stacks with horn bypass, order 1MMMSB meter socket assembly.

④ For top position, use meter socket cover 1MMRC125T.

Commercial meter stacks**Table 10. Commercial Meter Stacks (Lever Bypass)****Catalog Numbers**

| Meter Stack | Wireway Cover | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|-------------------|---------------|---------------|-----------------------|----------------------|-------------|-------------|-----------|--------------------------|-----------------------------|
| 35MM120R12 | MSLWCVR1 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM220R12 | MSLWCVR2 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM320R12 | MSLWCVR3 | — | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 35MM420R12 | MSLWCVR4 ① | MSLWCVR13 ② | MSLMSA1 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH2 | — | MSLEW2 |
| 37MM140R12 | MSLWCVR9 ① | MSLWCVR14 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM120R12 | MSLWCVR5 ① | MSLWCVR15 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM220R12 | MSLWCVR6 ① | MSLWCVR16 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM320R12 | MSLWCVR7 ① | MSLWCVR17 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH1 | — | MSLEW1 |
| 37MM420R12 | MSLWCVR8 ① | MSLWCVR18 ② | MSLMSA2 | MSBCVR1 | MSLMCVR1 ① | 37MMSK1 ② | MSLDH2 | — | MSLEW2 |

① Used for product built October 2002 and prior.

② Used for product built after October 2002.

Commercial meter stacks (continued)**Table 11. Commercial Meter Stack (Test Bypass)****Catalog Numbers**

| Meter Stack | Wireway Cover | Meter Socket Assembly | Tenant Breaker Cover | Meter Cover | Drip Hood | Endwall (with Knockouts) | Endwall (without Knockouts) |
|--------------------|----------------------|------------------------------|-----------------------------|--------------------|------------------|---------------------------------|------------------------------------|
| 35SS120RAB | MSTWCVR1 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS120RAC | MSTWCVR2 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS120RBC | MSTWCVR3 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 35SS220RAB | MSTWCVR4 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS220RAC | MSTWCVR5 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS220RBC | MSTWCVR6 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RAB | MSTWCVR7 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RAC | MSTWCVR8 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 35SS320RBC | MSTWCVR9 | MSTMSA1 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 37SS120R | MSTWCVR10 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW1 | MSTEWNK01 |
| 37SS220R | MSTWCVR11 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |
| 37SS320R | MSTWCVR12 | MSTMSA2 | MSBCVR1 | MSTMCVR1 | MSTDH1 | MSTEW2 | MSTEWNK02 |

Miscellaneous parts**Table 12. Miscellaneous Parts**

| Description | Part Number |
|--|--------------------|
| Phase balancing kit, single-phase commercial metering | 99-4177-3 |
| A and C phase balancing kit (3MM) | 99-4184 |
| Breaker mounting kit, commercial metering (one three-pole breaker per kit) | 99-4176-2 |
| Breaker mounting kit, 1MM/1MP, 200A, (one two-pole breaker per kit) | 99-4176 |
| Mounting kit, meter center | 99-4172 |
| Mounting kit, meter pack | 99-4173 |
| Bonding strap kit, all meter packs (except CECHA three and four socket) | 99-4174 |
| Bonding strap kit, CHECA three and four socket meter packs | 99-2379 |
| Sealing screw kit, ringless devices (six screws) | 99-4175 |
| Sealing screw kit, three and four meter sockets, ringless devices (four screws) | 99-2589 |
| Padlock bracket | 99-2512-5 |
| Mounting bracket kit—All breaker and fusible mains | 99-4183 |
| Mounting bracket kit—400A and 600A 3MTB | 99-4183-3 |
| Exterior breaker cover | 49-6070 |

Eaton Corporation
Electrical Sector
1111 Superior Ave.
Cleveland, OH 44114
United States
Eaton.com

© 2012 Eaton Corporation
All Rights Reserved
Printed in USA
Publication No. RP00501001E / Z11822
January 2012

Eaton is a registered trademark
of Eaton Corporation.

All other trademarks are property
of their respective owners.