

LANTERN BATTERIES

RAYOVAC® LANTERN BATTERIES

| Stock # / SKU | Description | Case Qty. | Stock # / SKU | Description | Case Qty. |
|---------------|---|-----------|---------------|--|-----------|
| 808C | RAYOVAC® Alkaline F Cell, 6V Battery, Spring Terminals | 4 | 945R4C | RAYOVAC® Zinc Carbon 6V Battery, Screw Terminals | 4 |
| 806C | RAYOVAC® Alkaline D Cell, 6V Battery, Spring Terminals | 6 | 918C | RAYOVAC® General Purpose, 6V Battery, Screw Terminals | 6 |
| 944C | RAYOVAC® Zinc Carbon 6V Battery, Spring Terminals | 4 | 926C | RAYOVAC® General Purpose, 12V Battery, Screw Terminals | 6 |
| 944-2RC | RAYOVAC® Zinc Carbon 6V Battery, Spring Terminals, 2 pack | 4 | 903C | RAYOVAC® Emergency 7.5V Multiple Ignition Battery with Screw Terminals | 4 |



808C or 806C



926C



944C



945R4C



944-2RC



926C



903C




LANTERN BATTERIES

RAYOVAC® LANTERN BATTERIES

| Stock # / SKU | Description | Case Qty. | Stock # / SKU | Description | Case Qty. |
|---------------|---|-----------|---------------|--|-----------|
| 808C | RAYOVAC® Alkaline F Cell, 6V Battery, Spring Terminals | 4 | 945R4C | RAYOVAC® Zinc Carbon 6V Battery, Screw Terminals | 4 |
| 806C | RAYOVAC® Alkaline D Cell, 6V Battery, Spring Terminals | 6 | 918C | RAYOVAC® General Purpose, 6V Battery, Screw Terminals | 6 |
| 944C | RAYOVAC® Zinc Carbon 6V Battery, Spring Terminals | 4 | 926C | RAYOVAC® General Purpose, 12V Battery, Screw Terminals | 6 |
| 944-2RC | RAYOVAC® Zinc Carbon 6V Battery, Spring Terminals, 2 pack | 4 | 903C | RAYOVAC® Emergency 7.5V Multiple Ignition Battery with Screw Terminals | 4 |



808C or 806C



926C



944C



945R4C



944-2RC



926C



903C

