

EZ/EZD Accessories



EZ700/500 Panel Window and Mounting Kit

Product Selection

Table 34.2-22. EZ/EZD Memory Storage Modules

Description	Catalog Number
EZ500/700 32K Memory Storage Module	EZ-M-32K
EZ800/EZD 256K Memory Storage Module	EZ-M-256K

Table 34.2-23. EZ/EZD Programming Cables

Description	Catalog Number
EZ500/700 to PC Cable	EZ-PC-CAB
EZ800/EZD to PC Cable	EZ800-PC-CAB

Table 34.2-24. EZ/EZD Cables and Connectors

Description	Catalog Number
EZ500/700 to EZD-CP4 Communication Cable, 5 m	EZD-CP4-500-CAB5
EZ800 to EZD-CP8 Communication Cable, 2 m	EZD-800-CAB
EZ800 to EZD-CP8 Communication Cable, 5 m	EZD-800-CAB5
EZ800 to EZD-CP4 Communication Cable, 5 m	EZD-CP4-800-CAB5
EZ800/EZD EZ-NET Cable, 0.3 m	EZ-NT-30
EZ800/EZD EZ-NET Cable, 0.8 m	EZ-NT-80
EZ800/EZD EZ-NET Cable, 1.5 m	EZ-NT-150
EZ800/EZD Network Termination Resistor, 2/Pack	EZ-NT-R
EZ800/EZD EZ-NET Cable (Cable Only, No Connectors, See EZ-NT-RJ45), 100 m	EZ-NT-CAB
RJ45 Network Connectors for EZ-NET Cable (EZ-NT-CAB), 10/Pack	EZ-NT-RJ45

Table 34.2-25. EZ/EZD Miscellaneous Parts

Description	Catalog Number
EZ500 Relay Simulator	EZ412-DC-SIM-NA
EZ500 Panel Window	EZSKF-FF4
EZ700/800 Panel Window	EZSKF-FF6
EZ500/700/800 Panel Window Mounting Kit to Front Mount Units	EZSKF-HA
EZ/EZD Panel Mount Brackets, 9/Pack	EZB4-101-GF1
EZ/EZD Grounding Kit	EZB4-102-KS1
EZD Display DIN Rail Mount Kit	EZD-TS144
EZD Display Protective Membrane Cover	EZD-XM-80
EZD Display Protective Plastic Cover	EZD-XS-80
EZ/EZD 6 Channel Noise Suppression Adapter	EZ256-HCI
EZ/EZD Spare Interface Connector, Base to Expander	EZ-LINK-DS
EZSoft Configuration Software	EZSOFT
EZ Starter Kit (Includes EZ512-DC-RC, EZ-PC-CAB, EZ412-DC-SIM-NA, EZSoft)	EZSTARTKIT1

Dimensions




Figure 34.2-14. EZ200-POW/EZ256-HCI and EZ400-POW Series Dimensions in Inches (mm), Drawing Number MD05013004E

EZ/EZD Accessories



EZ700/500 Panel Window and Mounting Kit

Product Selection

Table 34.2-22. EZ/EZD Memory Storage Modules

Description	Catalog Number
EZ500/700 32K Memory Storage Module	EZ-M-32K
EZ800/EZD 256K Memory Storage Module	EZ-M-256K

Table 34.2-23. EZ/EZD Programming Cables

Description	Catalog Number
EZ500/700 to PC Cable	EZ-PC-CAB
EZ800/EZD to PC Cable	EZ800-PC-CAB

Table 34.2-24. EZ/EZD Cables and Connectors

Description	Catalog Number
EZ500/700 to EZD-CP4 Communication Cable, 5 m	EZD-CP4-500-CAB5
EZ800 to EZD-CP8 Communication Cable, 2 m	EZD-800-CAB
EZ800 to EZD-CP8 Communication Cable, 5 m	EZD-800-CAB5
EZ800 to EZD-CP4 Communication Cable, 5 m	EZD-CP4-800-CAB5
EZ800/EZD EZ-NET Cable, 0.3 m	EZ-NT-30
EZ800/EZD EZ-NET Cable, 0.8 m	EZ-NT-80
EZ800/EZD EZ-NET Cable, 1.5 m	EZ-NT-150
EZ800/EZD Network Termination Resistor, 2/Pack	EZ-NT-R
EZ800/EZD EZ-NET Cable (Cable Only, No Connectors, See EZ-NT-RJ45), 100 m	EZ-NT-CAB
RJ45 Network Connectors for EZ-NET Cable (EZ-NT-CAB), 10/Pack	EZ-NT-RJ45

Table 34.2-25. EZ/EZD Miscellaneous Parts

Description	Catalog Number
EZ500 Relay Simulator	EZ412-DC-SIM-NA
EZ500 Panel Window	EZSKF-FF4
EZ700/800 Panel Window	EZSKF-FF6
EZ500/700/800 Panel Window Mounting Kit to Front Mount Units	EZSKF-HA
EZ/EZD Panel Mount Brackets, 9/Pack	EZB4-101-GF1
EZ/EZD Grounding Kit	EZB4-102-KS1
EZD Display DIN Rail Mount Kit	EZD-TS144
EZD Display Protective Membrane Cover	EZD-XM-80
EZD Display Protective Plastic Cover	EZD-XS-80
EZ/EZD 6 Channel Noise Suppression Adapter	EZ256-HCI
EZ/EZD Spare Interface Connector, Base to Expander	EZ-LINK-DS
EZSoft Configuration Software	EZSOFT
EZ Starter Kit (Includes EZ512-DC-RC, EZ-PC-CAB, EZ412-DC-SIM-NA, EZSoft)	EZSTARTKIT1

Dimensions




Figure 34.2-14. EZ200-POW/EZ256-HCI and EZ400-POW Series Dimensions in Inches (mm), Drawing Number MD05013004E