

## Accessories

### Auxiliary Contacts

#### XTPAXSA\_



#### Side-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXSA11                     |
| 1NO-2NC               |                  | 5           | XTPAXSA12                     |
| 2NO-1NC               |                  | 5           | XTPAXSA21                     |

Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR\_ and XTPAXFA\_ trip indicating auxiliary contact.

#### XTPAXFA11



#### Front-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXFA11                     |

Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

**Note**

① Orders must be placed in multiples of package quantity listed.

## Accessories

## Auxiliary Contacts

## XTPAXSA\_



## Side-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXSA11                     |
| 1NO-2NC               |                  | 5           | XTPAXSA12                     |
| 2NO-1NC               |                  | 5           | XTPAXSA21                     |

Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR\_ and XTPAXFA\_ trip indicating auxiliary contact.

## XTPAXFA11



## Front-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXFA11                     |

Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

**Note**

① Orders must be placed in multiples of package quantity listed.

## Accessories

### Auxiliary Contacts

#### XTPAXSA\_



#### Side-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXSA11                     |
| 1NO-2NC               |                  | 5           | XTPAXSA12                     |
| 2NO-1NC               |                  | 5           | XTPAXSA21                     |

Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR\_ and XTPAXFA\_ trip indicating auxiliary contact.

#### XTPAXFA11



#### Front-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXFA11                     |

Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

#### Note

① Orders must be placed in multiples of package quantity listed.

## Accessories

## Auxiliary Contacts

## XTPAXSA\_



## Side-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXSA11                     |
| 1NO-2NC               |                  | 5           | XTPAXSA12                     |
| 2NO-1NC               |                  | 5           | XTPAXSA21                     |

Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR\_ and XTPAXFA\_ trip indicating auxiliary contact.

## XTPAXFA11



## Front-Mount Auxiliary Contacts

| Contact Configuration | Contact Sequence | Pkg. Qty. ① | Screw Terminal Catalog Number |
|-----------------------|------------------|-------------|-------------------------------|
| 1NO-1NC               |                  | 5           | XTPAXFA11                     |

Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

**Note**

① Orders must be placed in multiples of package quantity listed.