


1


XTCEXS\_



#### Frames D–H, Side Mount (Snap-On) – Two-Pole

| Conventional Free Air Thermal Current, $I_{th} = I_e$ , AC-1 in Amps | Contact Configuration              | Circuit Symbol | Pkg. Qty. ① | Screw Terminal Catalog Number |
|--|------------------------------------|----------------|-------------|-------------------------------|
| 10   | 1NO–1NC                            |                | 1           | XTCEXSBN11                    |
| 10   | 1NO <sub>E</sub> –1NC <sub>L</sub> |                | 1           | XTCEXSBLN11 ②                 |
| 10   | 1NO–1NC                            |                | 1           | XTCEXSCN11 ③                  |

XTCEXS\_



#### Frames L–R, Side Mount (Screw Mount) – Two-Pole


| Conventional Free Air Thermal Current, $I_{th} = I_e$ , AC-1 in Amps | Contact Configuration              | Circuit Symbol | Pkg. Qty. ① | Screw Terminal Catalog Number |
|--|------------------------------------|----------------|-------------|-------------------------------|
| 10   | 1NO–1NC                            |                | 1           | XTCEXSBR11 ④                  |
| 10   | 1NO <sub>E</sub> –1NC <sub>L</sub> |                | 1           | XTCEXSBLR11                   |
| 10   | 1NO–1NC                            |                | 1           | XTCEXSCR11                    |

#### Notes

- ① Orders must be placed in multiples of package quantity listed.
- ② 1 early-make contact (1NO<sub>E</sub>), 1 late-break contact (1NC<sub>L</sub>).
- ③ To avoid duplicate terminal numbers in contact sequence, the XTCEXSCN11 should be used with Frame D when a top mount auxiliary is also installed.
- ④ For replacement only. XTCEXSBR11 and XTCEXSBLR11 cannot be added onto side mount auxiliaries that come with the Frames L–R contactors as standard. To add auxiliaries onto the included side auxiliaries on Frames L–R contactors, use XTCEXSCR11.

1


XTCEXS\_



#### Frames D–H, Side Mount (Snap-On) – Two-Pole

| Conventional Free Air Thermal Current, $I_{th} = I_e$ , AC-1 in Amps | Contact Configuration              | Circuit Symbol | Pkg. Qty. ① | Screw Terminal Catalog Number |
|--|------------------------------------|----------------|-------------|-------------------------------|
| 10   | 1NO–1NC                            |                | 1           | XTCEXSBN11                    |
| 10   | 1NO <sub>E</sub> –1NC <sub>L</sub> |                | 1           | XTCEXSBLN11 ②                 |
| 10   | 1NO–1NC                            |                | 1           | XTCEXSCN11 ③                  |

XTCEXS\_



#### Frames L–R, Side Mount (Screw Mount) – Two-Pole

| Conventional Free Air Thermal Current, $I_{th} = I_e$ , AC-1 in Amps | Contact Configuration              | Circuit Symbol | Pkg. Qty. ① | Screw Terminal Catalog Number |
|--|------------------------------------|----------------|-------------|-------------------------------|
| 10   | 1NO–1NC                            |                | 1           | XTCEXSBR11 ④                  |
| 10   | 1NO <sub>E</sub> –1NC <sub>L</sub> |                | 1           | XTCEXSBLR11                   |
| 10   | 1NO–1NC                            |                | 1           | XTCEXSCR11                    |

#### Notes

- ① Orders must be placed in multiples of package quantity listed.
- ② 1 early-make contact (1NO<sub>E</sub>), 1 late-break contact (1NC<sub>L</sub>).
- ③ To avoid duplicate terminal numbers in contact sequence, the XTCEXSCN11 should be used with Frame D when a top mount auxiliary is also installed.
- ④ For replacement only. XTCEXSBR11 and XTCEXSBLR11 cannot be added onto side mount auxiliaries that come with the Frames L–R contactors as standard. To add auxiliaries onto the included side auxiliaries on Frames L–R contactors, use XTCEXSCR11.